

SLK
170

Installation Instructions

D.J.H - Winddeflector



1) Contens of Delivery:

- 1 Plastic glass
- 2 Stainless steel brackets
- 2 Screws
- 2 Stickers

2) Preparation

Take enough time for the installation.

!!!ATTENTION!!! After removing of the protection foil the right to return the merchandise is voided.!

3) Maintenance

Clean the Plastic Glass Winddeflector only with our Cleaner. SUGGESTION: We recommend the use of CLEANER D-1000. D-1000 is a special Cleaner-Set with high cleaner and a micro fiber cloth.

4) Remove of the original Parts

- 1. Open the Rooftop
- 2. Push both seat to the front
- 3. Remove the plastic screws (Picture 1)
- 4. Remove the 2 brackets (Picture 2+3)

5) Installation of new Parts

- 1. Put the stickers on (Picture 4)
- 2. Mounting of the stainless steel brackets (Picture 5)
- 3. Put the glass in (Picture 6)
- 4. Handtighten the screws (Picture 7)
- 5. Remove the protections foil (Picture 8)
- 6. Turn in now the screws with not to much power (Picture 9+ 10)



Bild 1



Bild 2



Bild 3



Bild 4



Bild 5



Bild 6



Bild 7



Bild 8



Bild 9



Bild 10

